



Adhering to Excellence

DRITAC 8100 TONGUE & GROOVE FLOORING ADHESIVE CALCULATOR

To calculate the amount of adhesive to purchase, simply multiply the values supplied by the number of square feet of flooring you are going to install. For example: 6" planks require 240 lineal feet of adhesive per 100 square feet of flooring to be installed. If your job is 500 square feet, multiply 5 x 240 ln. ft. = 1,200 lineal feet. Now multiply the number of bottles you would need for 100 square feet by 5, or 5 x 3 bottles = 15 bottles.

GENERAL USAGE CHART

BASED ON 100 SQUARE FEET OF FLOORING

Plank Width	Lineal Feet	Number of Bottles
3" Wide Planks	340 Lineal Feet	4 Bottles
6" Wide Planks	240 Lineal Feet	3 Bottles
9" Wide Planks	180 Lineal Feet	2 Bottles
12" Wide Planks	140 Lineal Feet	2 Bottles

*Printed DriTac spread rate is 100-150 lineal feet per 16 oz. bottle

These calculations are based off 100 square feet of installed, floating wood floor planks 36" in length. Always apply the correct size bead of adhesive and follow the wood flooring manufacturer's guidelines and instructions for floating wood floor installations. Always make sure the wood flooring manufacturer recommends a floating installation. DriTac Flooring Products accepts no responsibility for improperly installed floors. These calculations include gluing the head of joints.

Usage will vary due to installation practices, this is a general guide. Planks are manufactured in many other widths. Always order more adhesive than you think you will need for each job, we suggest 20 to 25 percent more. It is very costly and time consuming to run out of adhesive on the job. You can always use leftover adhesive on another job.

If you have further questions about DriTac 8100 Tongue & Groove Flooring Adhesive, please call our help line (973) 614-9000. We would be happy to assist you.